

|   |   |  |
|---|---|--|
| Reference Bridging Pit Gauge                            | N88-12-RB   | Carrying Case, Reference Pit Gauge Main Blade, Reference Connector Blade, Reference End Blade, Reference Slider Blade, Two Tees, Dial Indicator, Hardware (Spare Magnet Cartridge, Nylon Jam Screws, Blade Fasteners & Allan Key). Multi Piece unit can be assembled in spanning or cantilevering (28 1/2") configurations for testing large areas of Corrosion. |
| Pit Gauge Calibration Block                             | N88-FBH   | Serialized (w/ Certification) Cold Finished Bar 152mm (6") x 76mm (3") x 25mm (1") with Surface Treatment. 4 Flat Bottom Holes; 2.5mm to 10mm in 2.5mm increments (0.100" to 0.400" in 0.100mm increments).  |
| <b>Contact Points</b>                                   |   |  |
| #1-Standard Tip   | Ø0.040" Dia.  | #1 Contact Point - Standard N88-S  |
| #2-Conical Tip  | Ø0.010" Dia.  | #2 Contact Point - Sharp Point N88-C   |
| #3-Needle Tip   | Ø0.005" Dia.  | #3 Contact Point - Needle Point (very delicate) N88-N  |
| Extension   | 0.50"-12.7mm  | Extends the length of contact point by 0.050" (12.7mm) +/-0.002" or 0.05mm   |
| Large Wooden Carrying Case (Reaching)                   | N88-WB  | Wood Carrying Case used for most Kits  |
| #0 Carrying Case (Junior Bridging Kit)                  | N88-9-C0  | Smallest Green Aluminum Frame Case (used for Jr. Bridging/Plus, as well as custom cases)   |
| #1 Carrying Case (Bridging and Bridging Reference)      | N88-9-C1  | Medium Green Aluminum Frame Case (used for Jr. Bridging Super, Bridging and Bridging Reference Gauges.   |
| #5 Carrying Case (Bridging and Bridging Reference Plus) | N88-9P-C5   | Longest Green Aluminum Frame Case (used for Bridging Plus and Bridging Reference Plus Gauges.  |
| Soft Leather Case (Bridging Reference Only)             | N88-9-8L  | Stylish Artisan Crafted Soft leather case, designed specifically for the Bridging Pit Gauge, with up to 4 pockets for Extender T's. Zipper closed, Wrist Strap and removable Shoulder Strap  |
| <b>Dial Indicators</b>                                  | N88-I - Imperial Group 1                                    |  |
|   | N88-M - Metric Group 1                                      |  |
|   | N88-D - Digital Group 2                                     |  |
|   | N88-DI - Digital Indicator Communication Cable and Software |  |